


# Load Paper On A Xerox 5775



- 1 Tray 1
- 2 Tray 2
- 3 Tray 3
- 4 Tray 4
- 5 Bypass

## Load the Paper



1. Open the Tray
2. Place the media in the tray. Media must be positioned against the left side of the tray. Paper must not be loaded above the maximum fill line.
3. Make sure that the paper guides just touch the paper. Close the paper tray.

## Confirm the Tray

A tray confirmation screen will appear on the touch screen, go ahead and confirm if simply refilling or change the size, type, or color, then confirm.