

# How to Print from a PC on 5765/5775 SECURE PRINT


## Choose Properties or Preferences



In your document, choose file and print. Go to the properties or printing preferences.

Choose any options for your job, job type, paper, 2-sided printing, stapling and/or hole-punching.

## Secure Print



Select the drop down box for Job Type, Select Secure Print.




Enter a 4-10 digit password in the field and once again to confirm, select ok and ok again to print.

# Secure Print Retrieval




At the touch screen, select Job Status Hard key.

Select your job in the list.



Select Release.



Type in the same passcode that you entered in your print driver.

Select Release Job.